

Découvrir le monde de
VEEV inPRIME™

Discover the world of
VEEV inPRIME™

Scan the QR code to discover
all flavours and activate our
services and programmes.



veev-vape.com/activate


Scannez le code QR pour
découvrir toutes les saveurs
et activer nos services et
programmes.

VEEV inPRIME™ Device User Guide



TURN ON

Press the Button
for 4 seconds
until the Status
Lights ramp-up
to the level of
battery charge.
Your device is
ready for use.



CHANGE POD

You can change the pod while your
device is turned on. After the pod is
inserted, your device is ready for use.




TURN OFF

Press the Button for 4 seconds until the
Status Lights ramp-down.

RESPONSIVE DRAW™ & SENSORIAL FEEDBACK

The RESPONSIVE DRAW™ feature
enhances the experience through a
vibration while puffing and Sensorial
Feedback uses vibrations to indicate
different device statuses. To activate,
change or deactivate vibration settings,
press the Button while taking a puff.
For details, visit veev-vape.com.



BATTERY LEVELS


Short press the Button, the Status
Lights will turn on to indicate the
battery level. When the battery is equal
or lower than 1%, the lowest Status Light
blinks **WHITE** 5 times. Your device should be
recharged to continue using.

LOW LIQUID DETECTION

The lowest Status Light
will blink **RED** then **WHITE**,
3 times. Ensure your device
is used upright. If the warning
persists, replace the pod to continue using.

ERROR NOTIFICATION

If your device is not working or
the lowest Status Light blinks
RED more than once, change
the pod. If the error persists,
RESET your device. For further
support visit veev-vape.com.



RESET

Press the Button for 10 seconds until
the Status Lights blink **WHITE** twice
and the device turns on. Your device
is RESET.

VEEV inPRIME™ device

VEEV inPRIME™
pod


Status
Lights

Button

Charging
Port*


*For optimal charging
performance, only
use the manufacturer
approved Charging
Cable (supplied in the
box) and a certified
Power Adaptor which
you should obtain
from a reputable
source. Refer to the
'Technical Data'
section of the
Safety Warnings
and Instructions
for details.

Guide d'utilisation de l'appareil VEEV inPRIME^{MC}



MISE EN MARCHÉ

Appuyez sur le bouton pendant 4 secondes jusqu'à ce que les indicateurs d'état s'allument progressivement pour indiquer le niveau de charge de la batterie. Votre dispositif est prêt à être utilisé.



CHANGER LA CARTOUCHE

Vous pouvez changer la cartouche lorsque votre dispositif est allumé. Une fois la cartouche insérée, votre dispositif est prêt à être utilisé.




ÉTEINDRE

Appuyez sur le bouton pendant 4 secondes jusqu'à ce que les indicateurs d'état s'éteignent progressivement.

RESPONSIVE DRAW^{MC} & RETOUR SENSORIEL

La fonction RESPONSIVE DRAW^{MC} améliore l'expérience à l'aide d'une vibration pendant l'inhalation, et le Retour sensoriel utilise des vibrations pour indiquer différents états de l'appareil. Pour activer, modifier ou désactiver les réglages de vibration, appuyez sur le bouton tout en inhalant. Pour plus de détails, rendez-vous sur le site veev-vape.com.



NIVEAUX DE BATTERIE


Appuyez brièvement sur le bouton : les indicateurs d'état s'allument pour indiquer le niveau de batterie. Lorsque la batterie est égale ou inférieure à 1 %, l'indicateur le plus bas clignote en **BLANC** 5 fois. Votre appareil doit être rechargé pour continuer à être utilisé.

DÉTECTION DE NIVEAU DE LIQUIDE BAS

L'indicateur d'état le plus bas clignote en **ROUGE** puis en **BLANC**, 3 fois. Assurez-vous que votre appareil est utilisé en position verticale. Si l'avertissement persiste, remplacez la cartouche pour continuer à l'utiliser.


NOTIFICATION D'ERREUR

Si votre appareil ne fonctionne pas ou si l'indicateur d'état le plus bas clignote en **ROUGE** plus d'une fois, remplacez la cartouche. Si l'erreur persiste, RÉINITIALISEZ votre appareil. Pour obtenir une assistance supplémentaire, rendez-vous sur le site veev-vape.com.



RÉINITIALISATION

Appuyez sur le bouton pendant 10 secondes jusqu'à ce que les indicateurs d'état clignent en **BLANC** deux fois et que l'appareil s'allume. Votre appareil est RÉINITIALISÉ.



Appareil VEEV inPRIME^{MC}

Cartouche VEEV inPRIME^{MC}

Indicateurs d'état

Bouton

Port de charge*

*Pour des performances de charge optimales, utilisez uniquement le câble de charge approuvé par le fabricant (fourni dans la boîte) et un adaptateur secteur certifié que vous devez obtenir auprès d'une source fiable. Reportez-vous à la section « Données techniques » des avertissements et instructions de sécurité pour plus de détails.